

Contemporary Clock

This Contemporary Clock follows similar instructions to the Time Flies Clock. Again, it is recommended you embellish and decorate your clock base before assembling the clock mechanism.



1. Place the rubber washer and gold washer onto the clock mechanism.



2. Take the clock mechanism and screw it into the hole on the clock base. The fit should be quite tight so the mechanism is stuck in place.



3. Take the hour hand and click onto the clock mechanism.



4. Take the minute hand and click onto the clock mechanism.



5. Take the second hand and click onto the clock mechanism.



6. Your clock is now assembled